

ENTER Apartment Number  
(up to 4 digits)

Enter Apt No  
[\_\_\_\_]

Enter Resident Name  
(maximum 15 characters)

Enter Resident Name  
[\_\_\_\_\_]

ENTER Dial Code  
(up to 4 digits)

Enter Dial Code  
----

ENTER Phone Number  
ADC SYSTEM ONLY  
Maximum of 18 digits  
Use "" to pause for 1 second

For "" PRESS 

For "-" PRESS 

Enter Phone Number  
-----

ENTER Relay Code  
NSL SYSTEM ONLY

Enter Relay Code  
[\_\_\_\_]

ENTER Line in Use

Line in Use  
[x] Line 1  
[\_] Line 2  
[\_] Line 3  
[\_] Line 4  
[\_] Line 5

ENTER Keyless Code  
Up to 6 Digits  
See User Guide for more info

Enter Keyless Code  
[\_\_\_\_\_]

ENTER Elevator Restriction  
Address

Enter Elev Rest Addr  
[\_\_]

ENTER Elevator Rest Relay

Enter Elev Rest Relay  
[\_\_]

ENTER Keyless Correlation

Keyless Code Corr  
[x] Main door rela  
[ ] Aux door relay

HIDE Display

Hide Display  
[x]

ENTER Ring Pattern  
NSL SYSTEM ONLY

Ring Pattern  
[x] Ring Pattern 1  
[\_] Ring Pattern 2  
[\_] Ring Pattern 3  
[\_] Ring Pattern 4  
[\_] Ring Pattern 5

IF CREATING A NEW RECORD  
YOU WILL SEE

New Record Added

## 4 DELETE A RECORD

FROM THE DATABASE MENU

Scroll DOWN  to **3 Delete Record**

PRESS 

YOU WILL NOW SEE THE LIST OF RESIDENTS


1212 Smith  
1213 Franklin  
1214 Darwin  
1215 Newton

Scroll UP  or DOWN  to the desired record

PRESS 

THE RECORD IS NOW DELETED

Next Generation  
Communications & Security



NAVIGATING MENUS

1 2 ABC 3 DEF ↑ Scroll UP

4 GHI 5 JKL 6 MNO ↓ Scroll DOWN

7 PQRS 8 TUV 9 WXYZ ENTER

\* 0 # CANCEL

Scroll LEFT Scroll RIGHT

ENTERING INFORMATION

SYMBOL KEY	
PRESS	
once	,
twice	-
3 times	(
4 times	)
5 times	/
6 times	&
7 times	1

* KEY	
PRESS	
once	moves cursor left

0 KEY	
PRESS	
once	deletes character
twice	space

# KEY	
PRESS	
once	moves cursor right

**1** ENTER CONFIGURATION MODE

PRESS

WHEN YOU SEE **1 Configuration** PRESS

ENTER PASSCODE (provided by installer)

YOU ARE NOW IN THE CONFIGURATION MENU

```

Main Menu
1 System Option
2 Database
3 Schedules
4 Holidays
5 Factory Dflt
6 Input/Output
7 Correlation
8 Change Passcode
9 Test LCD
    
```

**2** MANAGE RECORDS

ENTER CONFIGURATION MODE

Scroll DOWN to **2 Database**

PRESS

YOU WILL NOW SEE

```

Database
1 Add Record
2 Edit Record
3 Delete Record
4 Sort by Name
5 Sort by D-Code
6 Auto Program
7 Delete all Records
    
```

Scroll DOWN to your desired option

PRESS

YOU CAN NOW MANAGE RECORDS

**3** ADD/ EDIT A RECORD

FROM THE DATABASE MENU

Scroll to ADD NEW RECORD or EDIT RECORD

PRESS

If you chose EDIT RECORD scroll to the desired record

PRESS

Scroll to the desired information you wish to edit

PRESS